

Technical Information

Leracid® ECO-TOP Limescale cleaner



Characteristics

Leracid® ECO-TOP Limescale cleaner is an acidic decalcifying agent and surface cleaner with a new formula based on methanesulfonic acid - no negative odour. It can be used for descaling in hot water appliances, boilers, coffee machines, milk frothers and other devices. It cleans tiles, fittings, shower equipment, cooking pots and other surfaces in the kitchen.

Application

For general descaling of devices, we recommend using the 1-litre bottle with dosing cap. The volume scale printed on the label simplifies exact dosing. Make sure that the limescale to be removed is completely wetted or, in the case of devices, covered.

Dosage

Manual cleaning: 1 : 10

Device descaling: 100 ml / 1 litre water
Circulate solution through the devices or heat the solution. Then rinse thoroughly with water several times. Repeat the procedure if there is a lot of limescale.

Specification

pH value (concentrate): approx. 1
Colour: neutral
Odour: product-specific

Packaging Unit

1 litre bottle with flip hinge, 12 per carton
10 litre can



Responsible Care



Anyone using the products should be aware that chemical must be handled with caution. Recommendations for storage and hazard information are contained in the applicable materials safety data sheet. Spent solutions and residual product should be disposed of as required by the competent authorities. The information provided is based on our experience. As conditions vary, all information is given and advice provided without liability. Therefore, we cannot assume responsibility to damage caused to a third party.